



TRANSITIONS	
ADSEL	From ADSEL to OMAXIS: Via SIA R-320 to D15.0 SIA, then turn RIGHT via D13.0 Arc SIA.
BOSOM	From BOSOM to OMAXIS: Via SIA R-195 to D15.0 SIA, then turn LEFT via D13.0 Arc SIA.
ENARI	From ENARI to OMAXIS: Via SIA R-342 to D15.0 SIA, then turn RIGHT via D13.0 Arc SIA.
HAWLS	From HAWLS to OMAXIS: Via SIA R-003 to D15.0 SIA, then turn RIGHT via D13.0 Arc SIA.
IMADI	From IMADI to OMAXIS: Via SIA R-060 to D15.0 SIA, then turn RIGHT via D13.0 Arc SIA.
IMONI	From IMONI to OMAXIS: Via SIA R-266 to D24.0 SIA, then turn RIGHT to heading 114° to intercept the ISIA localizer at D17.0 SIA.
KEMBO	From KEMBO to OMAXIS: Via SIA R-124 to D15.0 SIA, then turn LEFT via D13.0 Arc SIA.
KESPA	From KESPA to OMAXIS: Via SIA R-137 to D15.0 SIA, then turn LEFT via D13.0 Arc SIA.
NUBOX	From NUBOX to OMAXIS: Via SIA R-310 to D15.0 SIA, then turn RIGHT via D13.0 Arc SIA.
PETSU	From PETSU to OMAXIS: Via SIA R-290 to D15.0 SIA, then turn RIGHT via D13.0 Arc SIA.
SANGSTER	From SIA VOR to OMAXIS: Via SIA R-280 outbound to D11.0 SIA, then turn LEFT via D13.0 Arc SIA.
SEKAM	From SEKAM to OMAXIS: Via SIA R-354 to D15.0 SIA, then turn RIGHT via D13.0 Arc SIA.
TABRI	From TABRI to OMAXIS: Via SIA R-171 to D15.0 SIA, then turn LEFT via D13.0 Arc SIA.
TILUP	From TILUP to OMAXIS: Via SIA R-025 to D15.0 SIA, then turn RIGHT via D13.0 Arc SIA.
ROUTING	
Hold at OMAXIS at ATC assigned altitude unless/until cleared by ATC to execute the ILS Rwy 07 Approach procedure.	

CHANGES: Procedure renumbered, KAPAR transition removed, HAWLS and TILUP transitions added, KEMBO transition revised.
© JEPPESEN, 2005, 2019. ALL RIGHTS RESERVED.